



ZUBEHÖR FRITEUSE

SKU: ACSFM10 - ACMCSFM20M

Friggitrici elettriche - Electric fryers - Friteuses electriques Elektrofritteusen - Freidoras electricas - Электрические фритюрницы						Friggitrici a gas - Gas fryers - Friteuses a gaz Gasfritteusen - Freidoras a gas - Газовые фритюрницы					
Mod.	FR4N FR44N	FR8N FR88N FR88RN	FR10RN FR1010RN	SFM18 SFM18D	SFM18 SFM18D	SF25P	SF10 SF10DM	SF10M SF10DM	SFM20M SFM20DM	SFM20M SFM20DM	
				standard 1 cesto 1 basket	optional 2 mezzi cesti 2 half baskets	standard 1 cesto 1 basket	standard 1 cesto 1 basket	optional 2 mezzi cesti 2 half baskets	standard 1 cesto 1 basket	optional 2 mezzi cesti 2 half baskets	
A	415 mm	430 mm	455 mm	545 mm		-	550 mm		545 mm		
B	235 mm	250 mm	275 mm	345 mm		480 mm	290 mm		345 mm		
C	180 mm			210 mm		55x2 mm	190 mm		180 mm		
D	135 mm	210 mm		265 mm	124 mm	450 mm	235 mm	110 mm	265 mm	135 mm	
E	100 mm	110 mm		150 mm		125 mm	95 mm		150 mm		
F	200 mm			255 mm		265 mm	210 mm		220 mm		
G	320 mm		370 mm			-					
H	200 mm	210 mm		295 mm		-	225 mm		340 mm		
I	299 mm		348 mm	402 mm		-	350 mm		402 mm		
L	170 mm	260 mm									
M	149 mm	238 mm		302 mm		-	260 mm		302 mm		



	ACSM10	ACMCSFM20M
	1 mezzo cesto - 1 half basket - 1 demi panier 1 halber Korb - 1 cesta pequena - 1 moy-koпama	
Mod.	SF10M SF10DM	SFM20M - SFM20DM SFM18 - SFM18D

ZUBEHÖR FRITEUSE

